



Tampere 70 M


Installation drawings



















Installation drawings

marking		length	pcs
	HAMMER BLOCK 70 MM		2
AR-1	45x95 FLOOR FRAME	3986	1
AR-1B	45x95 FLOOR FRAME CUTOUT FOR DRAINAGE	3986	1
AR-2	45x95 FLOOR FRAME	2000	16
AR-3	45x 70 FLOOR FRAME	2000	1
TL-1	28x120 DECKING BOARD	800	17+1
TL-2	28x120 DECKING BOARD	2090	1
PL-1	24x120 FLOOR BOARD	1960	18+3
PL-2	24x120 FLOOR BOARD	995	18+3

SR-1	70x145 ROOF RAFTER		4534	2	
KL-1	24x120 ROOF BOARD		2728	40+3	
SL-1	STP 14x121 CEILING BOARD SAUNA ROOM		2015	18+2	
SR-3	45x45 SUPPORT DETAIL FOR SL-1		2000	2	
					
RL-2	45x45 ROOF EDGE SUPPORT		4536	2	
RL-1	18x95 ROOF EDGE BOARD		~4,6	2	
RL-1	18x95 ROOF EDGE BOARD		~3,0	2	
SL-2	15x55 DISTANCE BOARD FOR SL-1		1995	4	
PP-1	15x55 FLOOR AND CEILING MOULDINGS		~2,1	12+4	
A-1	WINDOW 70x845x1792 DOUBLE GLASS			2	
A-2	WINDOW 70x690x1792 DOUBLE GLASS			1	
U-1	OUTSIDE DOOR 70x690x1860			1	
U-2	GLASS DOOR 70x690x1860			1	
	18x95 DOOR MOULDING	EXTRA	~2,4	2	
UK-1	18x95 DOOR MOULDING		1890	8	
UK-2	18x95 DOOR MOULDING		920	4	
UK-3	15x55 DOOR MOULDING		670	4	
AK-6	15x55 WINDOW MOULDING		1752	2	
AK-1	18x95 WINDOW MOULDING		1900	2	
AK-2	18x95 WINDOW MOULDING		1877	8	
AK-3	18x95 WINDOW MOULDING		1650	2	
AK-4	18x95 WINDOW MOULDING		900	2	
AK-5	18x95 WINDOW MOULDING		650	2	
TE-1	28x70 + 25x25 WINDOW FIXING FILLET "T"		1792	4	
TE-2	28x70 + 25x25 DOOR FIXING FILLET "T"		1860	4	
VS-1	GRID WALL 650x1715			1	
NP-1	70x70 CORNER POST		1776	1	



LM-1	BENCH MODULE 600x1992 + SUPPORTS			1	
LM-2	BENCH MODULE 400x1992 + SUPPORTS			1	
LM-3	BENCH MODULE 500x992 + SUPPORTS			1	
LM-4	OUTDOOR BENCH 563x750 + SUPPORTS			1	
	BENCH SUPPORTS "HALDEN M"			1	
LT-1	45x45 VERTICAL BENCH SUPPORT WITH REGULATIVE FEET	850		1	
	VENTILATION LOUVER WOOD D100			2	
	VENTILATION GRID METAL D100			4	
	PIR CEILING INSULATION 30x600x1200			6	
	FOIL TAPE			1	
RN-1	WATER DRAINAGE DETAIL 2000			1	
	3 MM BOARD FOR FLOOR SLOPE	1995		1	
	6 MM BOARD FOR FLOOR SLOPE	1995		1	
	9 MM BOARD FOR FLOOR SLOPE	1995		1	
	12 MM BOARD FOR FLOOR SLOPE	1995		1	
	TREADED ROD M10	2500		3	
	TREADED ROD M10	2210		3	
	DRIVE NUT FOR TREADED ROD			6	
	PLAIN WASHER FOR TREADED ROD			6	
	NUT FOR TREADED ROD			6	
	METAR CORNER FOR GRID WALL VS-1			3	
	PLAIN WASHER M5 FOR METAL CORNER			3	
	POST HEIGHT ADJUSTMENT FOR NP-1			1	
	SCREW 3,5x40 A2 STAINLESS FOR MOULDINGS			200	
	SCREW 4,2x55 A2 STAINLESS FOR DECKING AND ROOF EDGE			200	
	SCREW 3,5x50 FOR FLOOR BOARD			200	
	SCREW 4,5x60 FOR ROOF BOARD (EDGE)			200	
	SCREW 5,0x90 ASSY FOR FLOOR FRAME, WALL LOGS, BENCH SUPPORTS			200	






FLOOR FRAME 45x95

BEFORE INSTALLING THE FLOOR BOARDS, PLACE PLYWOOD BOARDS 3...12 MM TO GIVE A FLOOR SLOPE




FLOOR FRAME




SCREW 90 MM

CUTOUT 45x25
FOR WATER DRAINAGE


INSTALL THE WATER DRAINAGE DETAIL BEFORE FLOOR BOARDS
FIX WITH FLOOR MOULDING





FLOOR AND DECKING BOARDS




IN SAUNA ROOM:
BEFORE THE FLOOR BOARD, INSTALL FLOOR SLOPE DETAILS 3MM, 6MM, 9MM, 12MM



FIRST ROW





Use rubber hammer and hammer block




THREADED RODS

WHEN INSTALLING THE WALL LOGS,
PLEASE CHECK THAT ALL THE HOLES ARE DRILLED!






PLAN




A

B


C




WALL 1




2 176






WALL 2




WALL A



WALL B



WALL C





EDITED, UPDATE
 Mat: 145 x 70
 Quality:
 Name: general
 Similar: 2
 IDs: SR-1

ROOF PURLIN SR-1

GRID WALL VS-1


CORNER POST NP-1

650





14

70




1776

INSTALLATION OF THE GRID







Sliding bracket 35x35x130
Install with 5x40 screws
Use M5 washer with screw to allow the wall logs to sink
(do not tighten the screw 100%)



Fix the grid to corner post with a screw 5x80

CEILING INSULATION


SAUNA ROOM




CUT THE HOLE FOR CHIMNEY WHEN USING WOOD-BURNING HEATER (EXTRA DRAWING WITH POSITIONING MEASURES)

WINDOW MOULDINGS


Inside and outside mouldings are with the same length
Fix the mouldings with a 40 mm screws (stainless)



DOOR MOULDINGS 18x95 (2 DOORS)



BENCH SET



1. FIRST FIX THE BENCH SUPPORTS TO THE WALL
2. THEN LIFT THE BENCHES ON TOP OF THEM
3. FIX THE BENCHES WITH THE 70 MM SCREWS TO THE WALLS AND SUPPORTS
4. USE VERTICAL SUPPORT TO SUPPORT THE BENCH FROM THE MIDDLE