





Code	Berggren	Sheet	6
Drawing	Wall 1	Scale	1:60
Material	7.0x13.5	Date	22.12.2016
Designed by	Tuindexo	File	Berggren.dwg




Code	Berggren	Sheet	8
Drawing	Wall 3	Scale	1:60
Material	7.0x13.5	Date	22.12.2016
Designed by	Tuindeco	File	Berggren.dwg



Code	Berggren	Sheet	9
Drawing	Wall 4	Scale	1:60
Material	7.0x13.5	Date	22.12.2016
Designed by	Tuindecò	File	Berggren.dwg




Code	Berggren	Sheet	3
Drawing	Wall A	Scale	1:60
Material	7.0x13.5	Date	22.12.2016
Designed by	Tuindeco	File	Berggren.dwg




Code	Berggren	Sheet	4
Drawing	Wall B	Scale	1:60
Material	7.0x13.5	Date	22.12.2016
Designed by	Tuindecó	File	Berggren.dwg

Wall C ↗




Code	Berggren	Sheet	5
Drawing	Wall C	Scale	1:60
Material	7.0x13.5	Date	22.12.2016
Designed by	Tuindeco	File	Berggren.dwg


ASSEMBLING OF ROOF PERIPHERY BOARDS



ROOF GABLE




ROOF EAVES




Bergren
Doorframe connection with
wall beam

Door assembling


STEP 1.1




STEP 1.2




STEP 2.1




STEP 2.2




STEP 3.1




STEP 3.2




STEP 4.1




STEP 4.2




STEP 5.1





















































STEP 5.2






















Code	Berggren	Sheet	1
Drawing	Plan	Scale	1:60
Material	70x135	Date	22.12.2016
Designed by	Tuindeco	File	Berggren.dwg

Pos	Drawing Berggren	Amount	Section (mm)	Length (mm)		
001		1	70x68	5587		
002		1	70x135	5587		
003		1	70x135	5587		
004		1	70x135	5587		
005		1	70x68	5587		
006		16	70x135	5487		
007		8	70x135	5487		
008		1	70x135	5487		
009		1	70x68	5487		
010		4	70x135	5478		
011		4	70x135	5061		
012		2	70x135	3960		
013		16	70x135	3960		
014		8	70x135	3824		
015		4	70x135	3746		
016		8	70x135	3654		
017		1	70x68	3564		
018		7	70x135	3564		
019		13	70x135	3500		
020		1	70x135	3500		
021		1	70x135	2911		
022		1	70x135	2911		
023		1	70x135	2911		
024		1	70x68	2911		
025		1	70x68	2911		
Code	Berggren	Material	File	Berggren.dwg	Sheet	1/4

Pos	Drawing Berggren	Amount	Section (mm)	Length (mm)		
026		16	70x135	2811		
027		1	70x68	2811		
028		1	70x68	2811		
029		8	70x135	2811		
030		4	70x135	1870		
031		4	70x135	1687		
032		1	70x68	1023		
033		15	70x135	1023		
034		8	70x135	887		
035		16	70x135	830		
036		16	70x135	830		
037		2	70x135	670		
038		4	70x68	562		
039		4	70x135	470		
040		2	70x135	470		
041		8	70x102	426		
042		8	70x74	309		
043		32	70x135	270		
044		2	70x135	270		
045		34	70x135	270		
P1		4	140x140	2130		
PR2		3	45x145	5588		
PR4		3	45x145	5588		
PR1		3	45x145	2912		
PR3		3	45x145	2912		
Code	Berggren	Material	File	Berggren.dwg	Sheet	2/4

Pos	Drawing Berggren	Amount	Section (mm)	Length (mm)
	Roof board 	194	88x18	4040
	Eaves board	6	18x90	2833
	Eaves board support	4	18x40	4250
	Gable board 	4	18x145	4080
	Gable top	4	18x40	4080
PF	Post foot 	4		
R1	Rod M8 	8		1000
R2	Rod M8 	4		430
R3	Rod M8 	8		338
R4	Rod M8 	4		270
	Nut M8 	32		
	Washer M8 	32		
	Connector M8 	8		
	Screw 4,5x50 	24		
	Sliding lath 	2	27x27	2100
Extra		1	70x135	6000
MB	Assembling piece	3	44x60	500
FF	Wooden Fixing finger 	85	12x12	200
Code	Berggren	Material	File	Berggren.dwg
			Sheet	3/4

Pos	Drawing Berggren	Amount	Section (mm)	Length (mm)
	<p>Door 2290x2100</p> <p>Side slat: 1. 16x80x2460 mm 2 pcs 2. 16x80x2072 mm 4 pcs</p> 	1		
	<p>Door 890x2030</p> <p>Side slat: 1. 16x80x1010 mm 2 pcs 2. 16x80x1980 mm 4 pcs</p> 	1		
	<p>Window 1290x910</p> <p>Side slat: 1. 16x80x1490 mm 2 pcs 2. 16x80x1000 mm 4 pcs 3. 16x80x1270 mm 2 pcs</p> 	1		
Code	Berggren	Material	File	Berggren.dwg
			Sheet	4/4